




LD:1 2 3 4
AT-Link-EZ V1.4

AT-Link






AT-START 雅特力

AT-START-L021 V1.0



DIGITAL(#=PWM)



CN6



J3

J5

J8

USART1_TX

USART1_RX

GND

MISO

SCK

RESET

NSS

5V

MOSI

GND

PB11

J1

GND

B8

B7

B5

B3

A14

F6

A12

A10

A8

B14

B12

VDD

B9

BOOT0

B6

B4

A15

F7

A13

A11

A9

B15

B13

#11

#10

#9

#8

#7

#6

#5

#4

#3

#2

TX

RX

VDD

BOOT0

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET

SCK

MISO

NSS

USART1_RX

USART1_TX

GND

VDD

BOOT0

GND

VDD

1.8V

3.3V

IDD

GND

5V

MOSI

GND

PB11

RESET


SCK

MISO

NSS

USART1_RX

USART1_TX



AT32L021C8T7