

AT32 timer external clock mode B + Suspend mode

Introduction

This sample code is based on AT32F403A. It is used to demonstrate how to use AT32 MCU's external clock mode B and suspend mode.

In this sample case, PWM generated by TMR8 serves as an external clock signal of TMR3 and TMR4. Both TMR3 and TMR4 run in Suspend mode. The connected TMR3_CH1 with TMR4_CH2 is used as an input of Suspend mode. The TMR3 starts counting at input high, and the TMR4 starts counting at input low. As there is no TMR8 available on AT32415, users can set TMR1 or connect with an external PMW signal source when using this sample code.

Note: This sample code is written based on Artery's V2.x.x BSP. For other versions of BSP, users should pay attention to the differences in use.

Ap	plical	ble r	brodu	icts.
γvp	piicai		Jiouc	1010.

	AT32F403 series
	AT32F403A series
	AT32F407 series
Product series	AT32F413 series
	AT32F415 series
	AT32F435 series
	AT32F437 series

List of major peripherals used:

Peripherals	TIMER
-------------	-------

1 Quick start

1.1 Hardware resources

- 1) AT-START-F403A V1.x evaluation board
- 2) Serial output PA9 (via AT-Link-EZ)
- 3) DuPont line





1.2 Software resources

- 1) AT32F403A MCU and AT32F403A_407_Firmware_Library_V2.0.6 (BSP version)
- 2) TMR settings:
 - > TMR3/TMR4 is set in slave mode: external clock mode B + Suspend mode
 - TMR8_CH1(PC6) outputs PWM to TMR3_EXT(PD2) and TMR4_EXT(PE0), and it is used as an external clock of TMR3 and TMR4
 - When TMR3_CH1 (PA6) and TMR4_CH2(PB7) are connected with high levels, TMR3 starts counting, and LED3 toggles once upon an overflow event.
 - When TMR3_CH1(PA6) and TMR4_CH2(PB7) are connected with low levels, TMR4 starts counting, and LED4 toggles once upon an overflow event
 - When the levels are different on TMR3_CH1(PA6) and TMR4_CH2(PB7), LED2 is always ON, and a serial interface reports an error
- 3) Messages are output to PC via PA9 (USART1_TX). The current TMR's CNT value can also be output to PC by pressing a blue USER button on AT-START board.

Note: All of projects are built based on Keil 5. For the need to run in other compiling environments, user can make simple adjustments according to AT32xxx_Firmware_Library_V2.x.x\project\at_start_xxx\templates.

1.3 Example case

- 1) Hardware connection
 - Connect PD2 (TMR3_EXT) to PE0 (TMR4_EXT)
 - Connect PA6 (TMR3_CH1) to PB7 (TMR4_CH2)
 - Connect PC6 (TMR8_CH1) that generates PWM wave to PD2 (TMR3_EXT) and PE0 (TMR4_EXT) and use it an external clock of TMR3 and TMR4. Also users can connect with an external clock source.
 - Apply low/high level to PA6(TMR3_CH1) and PB7(TMR4_CH2). Download program and check.
- 2) Open\SourceCode\SC0002_SourceCode\utilities\SC0002_Demo\mdk_v5\counter.uvprojx, compile it and download to the evaluation board.
- 3) View print information via a serial interface:
 - > After reset, print prompt information
 - When different levels are applied to PA6 (TMR3_CH1) and PB7 (TMR4_CH2), LED2 is always ON. After pressing "USER" button, the message "Make sure that PA6 &PB7 is connected with the same electrical level" will be displayed via a serial interface.
 - When PA6 (TMR3_CH1) and PB7 (TMR4_CH2) are connected with low levels, TMR4 starts counting, and LED4 blinks. After pressing "USER" button, the current level information and TMR4 counting value will be displayed via a serial interface
 - When PA6 (TMR3_CH1) and PB7 (TMR4_CH2) are connected high levels, TMR3 start counting and LED3 blinks. After pressing "USER" button, the current level information and TMR3 counting value will be displayed via a serial interface.

Figure 2. Information print

Make sure that PA6 &PB7 is connected with the same electrical level. Make sure that PD2 &PE0 is connected with external signal Pls. Press the USER key to get the working TMR counter value. Make sure that PA6 &PB7 is connected with the same electrical level. Low Level Hang, TMR4 Counter= 31499 Low Level Hang, TMR4 Counter= 60345 High Level Hang, TMR3 Counter= 30706 High Level Hang, TMR3 Counter= 22283



2 Revision history

Date	Revision	Changes
2022.01.20	2.0.0	Initial release

IMPORTANT NOTICE - PLEASE READ CAREFULLY

Purchasers are solely responsible for the selection and use of ARTERY's products and services, and ARTERY assumes no liability whatsoever relating to the choice, selection or use of the ARTERY products and services described herein

No license, express or implied, to any intellectual property rights is granted under this document. If any part of this document deals with any third party products or services, it shall not be deemed a license granted by ARTERY for the use of such third party products or services, or any intellectual property contained therein, or considered as a warranty regarding the use in any manner of such third party products or services or any intellectual property contained therein.

Unless otherwise specified in ARTERY's terms and conditions of sale, ARTERY provides no warranties, express or implied, regarding the use and/or sale of ARTERY products, including but not limited to any implied warranties of merchantability, fitness for a particular purpose (and their equivalents under the laws of any jurisdiction), or infringement on any patent, copyright or other intellectual property right.

Purchasers hereby agree that ARTERY's products are not designed or authorized for use in: (A) any application with special requirements of safety such as life support and active implantable device, or system with functional safety requirements; (B) any aircraft application; (C) any aerospace application or environment; (D) any weapon application, and/or (E) or other uses where the failure of the device or product could result in personal injury, death, property damage. Purchasers' unauthorized use of them in the aforementioned applications, even if with a written notice, is solely at purchasers' risk, and Purchasers are solely responsible for meeting all legal and regulatory requirements in such use.

Resale of ARTERY products with provisions different from the statements and/or technical characteristics stated in this document shall immediately void any warranty grant by ARTERY for ARTERY's products or services described herein and shall not create or expand any liability of ARTERY in any manner whatsoever.

© 2022 Artery Technology -All rights reserved