

## AT32\_TMR and DMA Update PWM Duty Cycle Dynamically

### Introduction

This document takes AT32F403A as an example to introduces how to use AT32 TMR and DMA to update PWM duty cycle dynamically.

This sample code use TMR4 update event to trigger DMA1 to transmit data to TMR4 channel 2 data register (TMRx\_C2DT), so that to dynamically output PWM waveforms with different duty cycles in the TMR4 channel 2 (PB7).

*Note: The corresponding code in this application note is developed on the basis of V2.x.x BSP provided by Artery. For other versions of BSP, please pay attention to the differences in usage.*

Applicable products:

Part number	ARTERY AT32 family
-------------	--------------------

List of peripherals:


Main peripherals	TIMER
	DMA

# 1 Application method

## 1.1 Hardware requirements

- 1) AT-START-F403A V1.x evaluation board;
- 2) Logic analyzer or oscilloscope

Figure 1. AT-START-F403A V1.0 evaluation board



## 1.2 Software requirements

- 1) This demo uses AT32F403A, and the BSP version is AT32F403A\_407\_Firmware\_Library\_V2.0.6.
- 2) TMR configuration:
  - Configure the TMR4 channel 2(PB7) to generate PWM waveforms.
  - Configure DMA1 and set channel 7 (TMR4 update event) for request mapping; transmit different duty cycles in the memory to the TMR4 channel 2 data register (TMRx\_C2DT) to update the duty cycle dynamically.
- 3) Modify the “src\_buffer[]” array in *main.c* to set the required duty cycle; the array length is calculated by software automatically.

*Note: All projects are built around keil 5. If users want to use them in other compiling environments, please refer to AT32xxx\_Firmware\_Library\_V2.x.x\project\at\_start\_xxx\templates (such as IAR6/7, keil 4/5) for a simple change.*


## 1.3 Example of application

- 1) Hardware connection: Connect PB7(TMR4\_CH2) to logic analyzer or oscilloscope;
- 2) Open \SourceCode\SC0069\_SourceCode\_V2.0.0\utilities\SC0069\_Demo\mdk\_v5\Duty.uvprojx

then compile and download to the evaluation board;

- 3) Capture the PB7 waveform and verify the effect. In normal operation, TMR4\_CH2 (PB7) outputs the PWM waveform with corresponding duty cycle according to the variables in “uint16\_t src\_buffer[] = {10,20,30,40,50,60,70,80,90,10,20,30,40,50,60,70,80,90};”. The PWM waveform in this Demo is shown in Figure 2.

Figure 2. LA captures waveform



## 2 Revision history

Table 1. Document revision history

Date	Version	Revision note
2022.01.25	2.0.0	Initial release.

**IMPORTANT NOTICE – PLEASE READ CAREFULLY**

Purchasers are solely responsible for the selection and use of ARTERY's products and services, and ARTERY assumes no liability whatsoever relating to the choice, selection or use of the ARTERY products and services described herein.

No license, express or implied, to any intellectual property rights is granted under this document. If any part of this document deals with any third party products or services, it shall not be deemed a license grant by ARTERY for the use of such third party products or services, or any intellectual property contained therein, or considered as a warranty regarding the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

Unless otherwise specified in ARTERY's terms and conditions of sale, ARTERY provides no warranties, express or implied, regarding the use and/or sale of ARTERY products, including but not limited to any implied warranties of merchantability, fitness for a particular purpose (and their equivalents under the laws of any jurisdiction), or infringement of any patent, copyright or other intellectual property right.

Purchasers hereby agrees that ARTERY's products are not designed or authorized for use in: (A) any application with special requirements of safety such as life support and active implantable device, or system with functional safety requirements; (B) any air craft application; (C) any automotive application or environment; (D) any space application or environment, and/or (E) any weapon application. Purchasers' unauthorized use of them in the aforementioned applications, even if with a written notice, is solely at purchasers' risk, and is solely responsible for meeting all legal and regulatory requirement in such use.

Resale of ARTERY products with provisions different from the statements and/or technical features stated in this document shall immediately void any warranty grant by ARTERY for ARTERY products or services described herein and shall not create or expand in any manner whatsoever, any liability of ARTERY.

© 2022 Artery Technology -All rights reserved