

## AT32F421\_USART LIN\_2.2A Protocol Frame

---

### Introduction

This sample code is written to demonstrate how to use USART\_LIN 2.2A protocol frame.

Applicable products:

Product series	AT32F421xx
----------------	------------

List of major peripherals used:


Peripherals	USART
	GPIO

## 1 Quick start

### 1.1 Hardware resources

- 1) Two pieces of AT-START-F421 V1.0 evaluation boards (as master and slave)

Figure 1. AT-START-F421 V1.0 evaluation board



- 2) PA2 / PA3 is used as LIN's TX / RX, while PA9 is used to print output information

### 1.2 Software resources

- 1) SourceCode
  - USART\_LIN-2.2A\_V2.0.0 source code

*Note: All of projects are built based on Keil 5. For the need to run in other compiling environments, user can make simple adjustments according to AT32F421\_Firmware\_Library\_V2.x.x/project/at\_start\_f421/templates.*

### 1.3 Example case

- 1) Open USART\_LIN-2.2A\_V2.0.0 source code lin\_master and lin\_slave, compile and download them to the master and slave board respectively
- 2) Cross connect PA2 on one board to PA3 on another board, open serial interface assistant and view information (including master-sent data and slave-received data).

*Note: when testing, first reset slave and then the master.*

Figure 2. Test result


```

Slave:
start lin slave layer test..
before slave recive data:
frame PID: 0x23.
data LEN: 8Bytes.
0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x00
after slave recive data:
frame PID: 0x23.
data LEN: 8Bytes.
0x11 0x22 0x33 0x44 0x55 0x66 0x77 0x88
before slave return response:
frame PID: 0x24.
data LEN: 4Bytes.
0xAA 0xBB 0xCC 0xDD
after slave return response:
frame PID: 0x24.
data LEN: 4Bytes.
0xAA 0xBB 0xCC 0xDD
test end.

Master:
start lin master layer test..
before master send data:
frame PID: 0x23.
data LEN: 8Bytes.
0x11 0x22 0x33 0x44 0x55 0x66 0x77 0x88
after master send data:
frame PID: 0x23.
data LEN: 8Bytes.
0x11 0x22 0x33 0x44 0x55 0x66 0x77 0x88
before master recive response:
frame PID: 0x24.
data LEN: 4Bytes.
0x00 0x00 0x00 0x00
after master recive response:
frame PID: 0x24.
data LEN: 4Bytes.
0xAA 0xBB 0xCC 0xDD
test end.
  
```

- 3) To obtain a clear view of test results, it is possible to use a logic analyzer to display LIN master and slave TX waveforms.

Figure 3. Clear view of test results



## 2 Revision history

Table 1. Document revision history

Date	Revision	Changes
2021.12.01	2.0.0	Initial release

## IMPORTANT NOTICE – PLEASE READ CAREFULLY

Purchasers are solely responsible for the selection and use of ARTERY's products and services, and ARTERY assumes no liability whatsoever relating to the choice, selection or use of the ARTERY products and services described herein.

No license, express or implied, to any intellectual property rights is granted under this document. If any part of this document deals with any third party products or services, it shall not be deemed a license grant by ARTERY for the use of such third party products or services, or any intellectual property contained therein, or considered as a warranty regarding the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

Unless otherwise specified in ARTERY's terms and conditions of sale, ARTERY provides no warranties, express or implied, regarding the use and/or sale of ARTERY products, including but not limited to any implied warranties of merchantability, fitness for a particular purpose (and their equivalents under the laws of any jurisdiction), or infringement of any patent, copyright or other intellectual property right.

Purchasers hereby agrees that ARTERY's products are not designed or authorized for use in: (A) any application with special requirements of safety such as life support and active implantable device, or system with functional safety requirements; (B) any air craft application; (C) any automotive application or environment; (D) any space application or environment, and/or (E) any weapon application. Purchasers' unauthorized use of them in the aforementioned applications, even if with a written notice, is solely at purchasers' risk, and is solely responsible for meeting all legal and regulatory requirement in such use.

Resale of ARTERY products with provisions different from the statements and/or technical features stated in this document shall immediately void any warranty grant by ARTERY for ARTERY products or services described herein and shall not create or expand in any manner whatsoever, any liability of ARTERY.

© 2023 Artery Technology -All rights reserved